Signaling Appliances and Equipment for the Hearing Impaired

COMPANY
COOPER WHEELOCK INC
273 BRANCHPORT AVE
LONG BRANCH, NJ 07740-6830 United States

S5391

Audible strobes Model(s) *AS-1215 (d), AS-1230 (d), AS-24110 (d), AS-2415 (d), AS-2430 (d), AS-2475 (d)*

Audible strobes, ceiling mount, for indoor use Model(s) *AS-24100C (b), AS-2415C (b), AS-2430C (b), AS-2475C (b), AS-24MCC (b)*

Audible strobes, wall mount, for indoor use Model(s) *AS-1215W (b), AS-24110W (b), AS-2415W (b), AS-2430W (b), AS-2475W (b)*

Chime/multi-candela strobes, wall mount, for indoor use Model(s) *CH70-24MCW (b), CH90-24MCW (b)*

Horn/multi-candela strobes, wall mount, for indoor use Model(s) *HS4-24MCW (b), HS4-24MCWH (b)*

Horn/strobe covers Model(s) *EWR*

Horn/strobe damage stoppers Model(s) *EWP*

Horn/strobe/speaker damage stoppers Model(s) *EWR*

Horns/strobes, wall mount, for indoor use Model(s) *HS4-24150C (b), HS4-24150W (b), HS4-241575W (b), HS4-24177C (b), HS4-24177W (b), HS4-24185W (b)*

Horns/strobes, wall mount, for indoor use Model(s) *NS or NS4, followed by -1215W, -2415W, -2430W, -2475W, -121575W, -24110W or -241575W, followed by any two alpha/numeric characters indicating lettering and color.*

Multi-candela strobes, synchronous and non-synchronous, wall mount, for indoor use Model(s) *RSS(x)-24MCW (b)(e)(f)*

Multi-candela strobes, wall mount, for indoor use Model(s) *ZRS-MCW (b)(e)*

Multitone horn/multi-candela strobes, wall mount, for indoor use only Model(s) *MT-24MCW, followed by alpha or numeric characters indicating enclosure markings and product color.*

Multitone strobe signal, for wall or ceiling mount, indoor use only Model(s) *AMT or AMT4, followed by -24, followed by HSPW, IS, LS, LSM, MS, SL, SLM and SHPW, followed by three alpha or numeric characters indicating lens orientation, lens lettering and product color, may be followed by suffix NYC.*

Multitone strobe signal, wall or ceiling mount, for indoor use Model(s) *AMT or AMT4, followed by -12, followed by LS, LSM, MS, SHPW, SL or SLM, followed by three alpha or numeric characters indicating lens orientation, lens lettering and product color.*

Multitone strobe signals, for outdoor use Model(s) *AMT, followed by no suffix or 4, followed by 12 or 24, followed by WH or WM, 1575W or 75W, followed by any three alpha/numeric characters indicating lens orientation, lens lettering and lens color, may be followed by NYC.*

Multitone strobe signals, wall or ceiling mount, for indoor use only Model(s) *MT or MT4, followed by -12, followed by LS, LSM, MS, SHPW, SL, SLM, followed by any three alpha or numeric characters indicating lens orientation, lens lettering and product color.*

Multitone strobe signals, wall or ceiling mount, for indoor use only Model(s) *MT or MT4, followed by -24, followed by IS, HSPW, LS, LSM, MS, SHPW, SL or SLM, followed by any three alpha or numeric characters indicating lens orientation, lens lettering and product color.*

Multitone strobes signals Model(s) *MT, followed by 12 or 24 for voltage, followed by strobe/candela (1575 = 15 cd with 75 on axis, 75 = 75cd), followed by W for wall mount, followed by product lettering (eg-F -fire) and porduct color (R = red, W = white, S = silver/grey, X = special), example model code: MT-241575W-FR.*

Speaker/strobe enclosures Model(s) *SSB, for use with E50-24MCW, E50-24MCWH, E50-241575W.*

Speaker/strobes Model(s) *SA-S70-24MCW-FR, SA-S70-24MCW-FW, SA-S90-24MCC-FR, SA-S90-24MCC-FW*

Speaker/strobes, for indoor dry use mounted on the ceiling only Model(s) *S8-24MCC, S8-24MCCH*

Speaker/strobes, for indoor use Model(s) *E70-24MCW (b), E90-24MCW (b), ET70-24MCW (b), ET90-24MCW (b)*

Speaker/strobes, for indoor use only Model(s) *E60-24MCC (b), E60-24MCCH (b), E60-24MCW (b), E60-24MCWH (b), E70-241575W (b), E70-24MCC (b), E70-24MCCH (b), E70-24MCWH (b), E90-241575W (b), E90-24MCC (b), E90-24MCCH (b), E90-24MCWH (b), ET70-24MCC (b), ET70-24MCCH (b), ET70-24MCWH (b), ET80-24MCW (b), ET80-24MCWH (b), ET90-24MCC (b), ET90-24MCCH (b), ET90-24MCWH (b)*

Speaker/strobes, for outdoor use when used with IOB back box Model(s) *ET70WP-24115C (b), ET70WP-24135W (b), ET70WP-24177C (b), ET70WP-24185W (b), ET70WP-2475C (b), ET70WP-2475W (b)*

Speaker/strobes, wall mount, for indoor dry use Model(s) *E50-241575W (b), E50-24MCW (b), E50-24MCWH (b)*

Speaker/strobes, wall or ceiling mount, for indoor use Model(s) *ET-1010, ET-1011, ET-1080, ET-1081, followed by suffix LS-24, LSM-24, MS-24, IS-24, HSW-24, SL-24, SLM-24, SHW-24, followed by three alpha or numeric characters indicating lens orientation, lens lettering and product color.*

Speakers with multi-candela strobes, wall mount, for indoor use Model(s) *ET70-24MCW (b), ET90-24MCW (b)*

Speakers, for indoor use Model(s) *E60, E70, E90, may be followed by additional suffix letters to indicate product color and mounting options.*

Strobe chimes, ceiling mount, for indoor use Model(s) *CH70 or CH90, followed by -2415C, -2430C, -2475C, -24100C, -24MCC, -24MCCH, followed by two alpha or numeric characters indicating lettering and product color.*

Strobe chimes, wall mount, for indoor use Model(s) *CH70 or CH90, followed by -2415W, -2430W, -2475W, -24110W, -241575W, -24MCW, -24MCWH, followed by two alpha or numeric characters indicating lettering and product color.*

Strobe lights (110cd), wall or ceiling mount, for indoor use Model(s) *HS1W-12 (d), HS2W-12 (d), HS3W-12 (d), HSPW-12 (d), HSW-12 (d)*

Strobe lights, synchronous and non-synchronous, ceiling mount, for indoor use Model(s) *RSSWP-2475C (b)(c)*

Strobe lights, synchronous and non-synchronous, selectable candela (115 or 177cd), for indoor use mounted on the ceiling only Model(s) *RSS-24MCCH (b)(e), RSS-24MCCHR (b)(e), RSSP(x)-24MCCH (b)(e)(f), ZRS-MCCH (b)(e)*

Strobe lights, synchronous and non-synchronous, selectable candela (135 or 185cd), for indoor use mounted on the wall only Model(s) *RSS-24MCWH (b)(e), RSSP-24MCWH (b)(e), ZRS-MCWH (b)(e)*

Strobe lights, synchronous and non-synchronous, selectable candela (15, 15/75, 30, 75, 95, 110, 135 or 185cd), for indoor use mounted on the wall only "Exceder Series" Model(s) *ST, followed by R (Red) or W (White), may be*

followed by S (Silver fascia), followed by (X) indicating lens lettering.

Strobe lights, synchronous and non-synchronous, selectable candela (15, 30, 60, 75, 95, 115, 150 or 177cd), for indoor use mounted on the ceiling only "Exceder Series" Model(s) *ST(X)C, where X indicates color - R (Red) or W (White), may be followed by S (Silver fascia), followed by (X) indicating lens lettering.*

Strobe lights, synchronous and non-synchronous, selectable candela (15, 30, 75 or 110cd), for indoor use mounted on the wall only Model(s) *ZRS-MCW (b)(e)*

Strobe lights, synchronous and non-synchronous, selectable candela (15, 30, 75 or 95cd), for indoor use mounted on the ceiling only Model(s) *RSS-24MCC (b)(e), RSS-24MCCR (b)(e), RSSP(x)-24MCC (b)(e)(f), ZRS-MCC (b)(e)*

Strobe lights, synchronous and non-synchronous, selectable candela (15, 30, 75 or 95cd), for indoor use mounted on the wall only Model(s) *ZRS-MCC (b)(e)*

Strobe lights, synchronous and non-synchronous, selectable candela type, for indoor use on the wall Model(s) *RSS(X)-121575W (b)(e)(f), RSS(X)-1215W (b)(e)(f), RSSP(x)-121575W (b)(e)(f)*

Strobe lights, synchronous and non-synchronous, wall mount, for indoor use Model(s) *RSS(X)-121575W (b)(e)(f), RSSP(x)-121575W (b)(e)(f)*

Strobe lights, synchronous, wall mount, for indoor use Model(s) *RSS-24185W (b), RSSP-24185W (b)*

Strobe speakers, ceiling mount, for indoor use Model(s) *ET70, ET90, followed by -2415C, -2430C, -2475C, -24100C, -24150W, -24177W or -24185W, followed by two alpha or numeric characters indicating lettering and product color.*

Strobe speakers, wall mount, for indoor use Model(s) *ET70, ET90, followed by -2415W, -241575W, -2430W, -2475W, -24110W, -24150C or -24177C, followed by two alpha or numeric characters indicating lettering and product color.*

Strobe/speakers, for indoor use only Model(s) *E90-24 (b), ET70-24 (b)*

Strobe/speakers, wall mount, for indoor use Model(s) *RSS(x)-121575 (b)(e), RSS(x)-1215W (b)(e), RSS(x)-241575 (b)(e), RSSX-24110W (b)(e), RSSX-24150W (b)(e), RSSX-2415W (b)(e), RSSX-24177W (b)(e), RSSX-24185W (b)(e), RSSX-2430W (b)(e), RSSX-2475W (b)(e)*

Strobe/speakers, wall or ceiling mount, for indoor use Model(s) *RSSX-24100C (b)(e), RSSX-24150C (b)(e), RSSX-2415C (b)(e), RSSX-24177C (b)(e), RSSX-2430C (b)(e), RSSX-2475C (b)(e)*

Strobes, synchronous (110cd), wall or ceiling mount, for indoor use Model(s) *SH1W-12 (d)(e), SH2W-12 (d)(e), SH3W-12 (d)(e), SHPW-12 (d)(e)*

Strobes, synchronous (15/75cd), wall or ceiling mount, for indoor use Model(s) *SLM-12 (d)(e), SLM1-12 (d)(e), SLM2-12 (d)(e), SLM3-12 (d)(e), SLMP-12 (d)(e)*

Strobes, synchronous (15cd), wall or ceiling mount, for indoor use Model(s) *SL-12 (d)(e), SL1-12 (d)(e), SL2-12 (d)(e), SL3-12 (d)(e), SLP-12 (d)(e)*

Strobes, synchronous and non synchronous, for ceiling mount, indoor use Model(s) *RSS -24100C (b)(e), RSS -24100CR (b)(e), RSS -24150C (b)(e), RSS -24150CR (b)(e), RSS -2415C (b)(e), RSS -2415CR (b)(e), RSS -24177C (b)(e), RSS -24177CR (b)(e), RSS -2430C (b)(e), RSS -2430CR (b)(e), RSS -2475C (b)(e), RSS -2475CR (b)(e)*

Strobes, synchronous and non synchronous, selectable candela type, ceiling use, for indoor use Model(s) *RSSWP-24MCCH (b)(c)*

Strobes, synchronous and non synchronous, selectable candela type, wall use, for indoor use Model(s) *RSSP(x)-24MCW (b)(e)(f), RSSWP-24MCWH (b)(c)*

Strobes, synchronous and non synchronous, wall mount, for indoor use Model(s) *RSS-121575W (b)(e), RSS-1215W (b)(e), RSS-21450W (b)(e), RSS-24110W (b)(e), RSS-2415W (b)(e), RSS-24177W (b)(e), RSS-24185W (b)(e), RSS-2430W (b)(e), RSS-2475W (b)(e), RSSWP-2475W (b)(c)*

(b) - All model numbers may be followed by alphanumeric characters indicating lettering and product color

(c) - Complementary Listed (UVAV) for Private Mode Emergency use when used indoors or outdoors.

(d) - Followed by three alpha or numeric characters indicating orientation, lettering and product color.

(e) - Use SM or DSM Sync modules with strobes for sync mode.

(f) - Where (X) - R indicates lens color is red, B indicates lens color is blue, G indicates lens color is green and A indicates lens color is amber, No (X) designator indicates White or Clear; Models with colored lens (except white or clear) are intended for private mode use.

Trademark and/or Tradename: "Cooper Notification", "Wheelock"

Last Updated on 2023-01-24

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL Solutions' Follow - Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL Solutions' Follow - Up Service. Always look for the Mark on the product.

UL Solutions permits the reproduction of the material contained in Product iQ subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from Product iQ with permission from UL Solutions" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "©2026 UL LLC."